01 安装与添加设备

Install the app & add your clock

下载 InkWatch 安卓应用

Download InkWatch for Android

inkwatch.truelysia.com


扫码或点击链接，下载并安装 APK。

Scan or tap the link to download and install the APK.

APP 下载 / App


让设备保持开启；未开启时，按下设备背部按钮。打开手机蓝牙，按 App 提示允许附近设备和相机权限。

Keep the clock on; press its rear button if it is off. Turn on phone Bluetooth and allow nearby-device and camera access when prompted.



1 点击 Add a clock（添加设备）

Open InkWatch and tap Add a clock.



2 扫描自己设备屏幕上的二维码，按 App 引导完成配对。

Scan the QR code on your own clock and follow the app to pair it.

图中二维码仅作示意。配对时请扫描自己的设备。

The QR code in the photo is an example. Scan your own clock to pair.

安装时，如系统提示，请允许本次安装，完成后打开 InkWatch。


If Android asks, allow this installation, then open InkWatch.


02 联网与首次设置

Connect Wi-Fi & finish setup

按 Finish setup（完成设置）引导，确认时区、连接 Wi-Fi，再选择首页行情。

Use Finish setup to check the time zone, connect Wi-Fi and choose a home quote.





仅支持 2.4 GHz Wi-Fi；不支持需要网页登录的网络。

Use 2.4 GHz Wi-Fi. Networks that need a web sign-in are not supported.

1 进入 Wi-Fi 设置

点击 Wi-Fi 或 Set up: Wi-Fi。

Tap Wi-Fi or Set up: Wi-Fi.

2 先扫描，再输入密码

点击 Let the clock scan for networks，选择网络，输入密码后点击 Join。

Tap Let the clock scan for networks, choose your network, enter its password, then tap Join.

3 选择首页行情

返回引导，点击 What to show，选择首页要显示的行情；也可以只显示时间。


Return to setup and tap What to show. Choose a home quote, or keep the home page as time only.

03 屏幕内容

On the clock

点击对应卡片，分别设置三个页面的行情内容。

Tap a card to choose what each clock page shows.



A 首页

Home

显示时间，可附带一条行情摘要。

Time, with an optional quote summary.

B 单标的页

Single instrument

集中显示一个标的的价格与涨跌幅。

The price and change of one instrument.

C 三行情页

Three quotes

同屏显示最多三条行情，可以不选满。

Up to three quotes on one screen; fewer is fine.


设备背部上键：短按切换页面。 / Short-press the upper rear button to change pages.

04 常用设置

Settings at a glance

在设备详情页向下滚动，即可找到 Settings（设置）。

Scroll down on the clock detail page to find Settings.



1 更新与涨跌周期

Quote updates and change period

选择行情多久更新，以及涨跌幅的比较周期。

Choose the update interval and the period used to compare prices.

2 时区

Time zone

设置设备显示时间所用的地区。

Choose the region used for the clock's time.

3 Wi-Fi

Wi-Fi

连接或更换设备使用的无线网络。

Connect the clock to Wi-Fi or change its network.

4 演示模式

Demo mode

使用模拟行情，Wi-Fi 关闭。需在 App 手动退出；重启不会退出。

Simulated quotes, Wi-Fi off. Exit in the app; restarting keeps demo on.

5 行情灯

Market light

开关背部行情灯，颜色跟随当前页面行情。

Switch the rear quote light on or off. Its colour follows the current page.

6 固件更新

Firmware

查看设备版本，有更新时按提示操作。

Check the version; follow the prompts to update.

7 移除设备

Remove clock

先看确认提示；连接时移除会清除设备设置。

Read the confirmation: removing a connected clock clears its settings.

恢复正常行情前，记得关闭 Demo mode。 / Turn Demo mode off to return to normal quotes.